

Juland Electronics 600 Series Switchgauge & EFI PetrolStart Timer Installation Instructions - Latest style with connector & loom

- 1 Remove vehicle blank
- 2 Poke free end of loom through hole - leave white connector 4" - 6" free (100mm - 150mm)
- 3 Connect all wires
- 4 Plug connector into Switchgauge
- 5 Test to see it works
- ⇒ Select Petrol = Amber Led Lights up + Power on Yellow
- ⇒ Select Gas = Gauge Lights up + Power on Green Wire
- ⇒ Adjust Trimpot clockwise for longer Petrol-Start time.
- 6 If gauge Led's are too bright, remove black mini-jumper marked 'BRITE' near Timer Trimmer
- 7 Plug Switchgauge into hole.

White Wire Note:

The 600 Series can be set to **Automatically Petrol-Start at ignition-on**
Install jumper to link L2 on PCB adjacent to white connector (see diagram)
(Ensure the White Wire is NOT connected when bridging jumper L2)

Juland Electronics P/L... for a quality conversion

