


Juland Electronics Tachometric Start Module TSM3

Installation Instructions

Features: Change on Accel. +Adjustable Injector Hold-on + Safety-Switch + Loom



Introduction:

The TSM3 is designed for use with a Juland "500" Series SwitchGauge. Other switches can be used, but this involves cutting-off the 6-pin plug to wire the switch. Call Juland for advice on using the TSM3 in this way.

Installation:

- Select the position for the Juland 500 Series SwitchGauge and remove the blanking plate
 - Poke the loom through the hole and pull it through till the 6-pin plug is left with about 10cm of slack
 - Connect the 6 wires of the other end of the loom as indicated here:-
- | | | |
|--------------------------|-----------------------|------------------------|
| ⇒ Yellow = Petrol | Green = Gas | Blue = Sender |
| ⇒ Red = Ignition | Black = Ground | White = Coil-Ve |
- Plug in the SwitchGauge (6-pin plug) and the TSM3 (8-pin plug)
 - Adjust the trimpots to the desired settings
 - Test to see it works correctly
 - Insert the SwitchGauge into the hole
 - Secure the TSM3 using either the screws supplied, or with a cable-tie (not supplied)
 - **Do not crush the box if mounting it with the screws**

SPECIAL NOTE - White Wire:

On a VR-VS Commodore, the White Wire can be connected to the brown Tacho wire found near the passenger side shock

Important:

- The **LEFT** Trimpot sets the revs. at which the change-over will occur
- The **RIGHT** Trimpot sets the Injector hold-on time. Fully anticlockwise = no hold-on
- **The Rev Range for a 6 Cylinder, Distributor Engine (ie: 3 sparks/rev.) is:- 720rpm-2200rpm**
- **For Distributorless Ignition Systems (ie: 6 sparks/rev.), remove the 'Link' beside the connector (indicated above)**

Other Features:

- The Green Led on the front of the TSM3 indicates Gas output on, and the Amber indicates Petrol
- Whenever the Safety-Switch time-out occurs, the TSM3 will select Petrol, regardless of the position of the Gas/Petrol switch

Straight-Gas-Start:

'Straight-Gas-Start' is achieved by the following procedure:-

- 1 Turn Ignition on
- 2 Switch to Petrol then back to Gas
- 3 Start the engine

CAUTION

- ⇒ **Check all wiring prior to switching on.**
- ⇒ **If problems exist, re-check all your connections; then email us:- info@juland.com.au**

Juland Electronicsfor a quality conversion
www.juland.com.au