

**Juland Electronics P/L**  
**“800” Series Switch and Fuel-Gauge Relay with Loom**  
**Installation Instructions**

- 1 Remove vehicle blank
  - 2 Poke free end of loom through hole - leave white connector 4” - 6” free (100mm - 150mm)
  - 3 Connect all wires
  - 4 Plug connector into Switchgauge
  - 5 Test to see it works
- ⇒ Select Petrol = Amber Led on + Yellow loom Wire +12v  
⇒ Select Gas = Green Led on + Green loom Wire +12v

**Loom Wire Colour Code:-**

Red	=	+12v Ignition
Black	=	Earth / Ground
Yellow	=	PETROL
Green	=	GAS
White	=	Unused
Blue	=	Unused

**Fuel-Gauge Relay**

There are three separate wires with Spade Terminals for Fuel-Gauge changeover between Petrol Tank and Gas Tank

**Spade Wire Colour Code:-**

White	=	Car Gauge
Green	=	Gas Sender
Yellow	=	Petrol Sender

**Juland Electronics .... for a quality conversion**

Phone: (03)5729-8486

**Internet:** [www.juland.com.au](http://www.juland.com.au)    **email:** [info@juland.com.au](mailto:info@juland.com.au)